

C253B Clock Radio/TV with Dual Alarm

FCC Warnings

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.


Additional Warnings

- Mains plug is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.
- The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on apparatus.
- Do not place the unit on top of any soft, porous, or sensitive surfaces to avoid damaging the surface. Use a protective barrier between the unit and surface to protect the surface.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.
- Batteries should be recycled or disposed of as per state and local guidelines.
- WARNING: This product may contain chemicals known to the State of California to cause birth defects, or other reproductive harm (California Prop 65). Wash hands after handling.
- This product meets and complies with all Federal regulations.

Introduction and Setup

Power



Plug the included AC/DC power adapter into the **DC POWER INPUT** on the dock and an AC power outlet to power the dock.



Battery Backup

The battery backup is intended for short power outages only. The clock radio's primary functions cannot run off of the battery backup alone.

Requires 2, AAA-size, batteries (not included)



Dimmer

Press to dim the display.

Line Input

Tuning/Min/Hour

Press to tune the radio.
Press to adjust the minute or hour when setting the clock or alarm.

Clock/Mem

In Off mode, press and hold to begin setting the time.
In radio mode, press to cycle through preset stations.

Snooze/Sleep


Press to snooze the alarm after it sounds. In on mode, press repeatedly to set the sleep timer.

Volume/AL1/AL2

Press to adjust the volume. Press to begin setting Alarm 1 or Alarm 2. Note: Volume will not function in line in mode.

Source/AL Off

Press repeatedly to switch between Line in, FM, or AM Radio modes. Press and hold to turn off the radio. Press to turn off the alarm.



PM Indicator

Lights when the time is in the PM.



Alarm 1 Buzzer/ Radio Indicator

Lights when the alarm 1 is on and set to buzzer or radio.

Alarm 2 Buzzer/ Radio Indicator

Lights when the alarm 2 is on and set to buzzer or radio.

Clock and Sleep Timer

Setting the Clock

1. If in radio mode, press and hold the **Source/AI Off** button to turn the unit off.
2. Press and hold the **Clock/Mem** button until the display begins to blink, then release the button.
3. Press the **Hour** button to adjust the hour.

The PM indicator will light when the hour is set in the PM.

4. Press the **Min** button to adjust the minute.
5. Press the **Clock/Mem** button to finish setting the time.

Setting the Sleep Timer

1. Press the **Snooze/Sleep** button repeatedly to set the sleep timer (90, 80, 70, 60, 50, 40, 30, 20, 10 min or OFF).
2. Once the set sleep time has expired the clock radio will automatically power off.

Radio

Tuning the AM or FM Radio

1. Press the **Source/AI Off** button to turn the clock radio on.
2. Press the **Source/AI Off** button again to switch between the AM and FM radio mode.
3. Press the **Tun+** and **Tun-** buttons to adjust the radio to the desired frequency.
4. Press and hold the **Tun+** and **Tun-** buttons to search for the next available frequency.
5. Press the **Vol+/-** buttons to adjust the volume.
6. Press and hold the **Source/AI Off** to turn the radio off.

Saving a Station as a Preset

1. Follow the instructions for [Tuning the AM or FM Radio](#).
2. Tune to the desired station.
3. Press and hold the **Clock/Mem** button to save the current radio station as a preset.

Tuning to a Preset Radio Station

1. Follow the instructions for [Tuning the Radio](#) and [Saving a Station as a Preset](#).
2. Press the **Clock/Mem** button to cycle through preset radio stations.

Radio Reception

Adjust the position of the **FM Antenna** to improve FM radio reception.

An AM antenna is built into the clock radio. To improve AM radio reception, adjust the position of the clock radio.

Line Input

Using the Line Input

Requires a 3.5mm audio cable (not included).

1. Connect a 3.5mm audio cable to the **Line Input** and the audio output on an MP3 player or other audio device.
2. Press the **Source/AI Off** to switch to Line in mode.

The display will show "AU"

3. Use the native controls on the connected MP3 player or other audio source to play your audio through the unit. The volume buttons on the unit will not function in line in mode, so it is necessary to use the controls on the native device.

When not in use, make sure to disconnect the 3.5mm audio cable (not included).

Alarm

Setting the Alarm

1. If in radio mode, press and hold the **Source/AI Off** button to turn the unit off.
2. Press the **AI1** or **AI2** button.
3. Press the **Hour** button to adjust the hour.

The PM indicator will light when the hour is set in the PM.

4. Press the **Min** button to adjust the minute.

The Alarm 1 or Alarm 2 indicator will come on.

5. Press the **AI1** or **AI2** buttons repeatedly to switch between Radio, Buzzer or off.
6. Once the set alarm time is reached, the alarm will sound.

To set the other alarm, follow the above steps and choose the alarm not currently set.

Canceling the Alarm

1. Follow the instructions for [Setting the Alarm](#).
2. Press the **AI1** or **AI2** buttons repeatedly until the indicator is no longer lit.

After the alarm sounds:

Snooze and Alarm Reset
delay the alarm for an additional 9 minutes.

OR

Press the **Source/AI Off** button to turn the alarm off until the set alarm time is reached again.



International Support

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at:

www.gpx.com

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en

www.gpx.com

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur

www.gpx.com

For Warranty Information and the most up-to-date version of this User's Guide, go to www.gpx.com Customer Service: 1-888-999-4215

Email Support: prodinfo@dpiinc.com, Email Parts: partinfo@dpiinc.com

Copyright © 2013 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.