

12.5" Pizza Pan / Flat Griddle with Detachable Handle

READ AND FOLLOW CARE AND USE INSTRUCTIONS BEFORE FIRST USE. Before using your new cookware, wash thoroughly in hot soapy water using a soft cloth or sponge. Dry completely. For better non-stick performance, it is recommended to add a teaspoon of cooking oil prior to each use. Never heat an empty cooking utensil. Be sure there is oil, butter or food in the cookware before placing it on the range or burner. Always use low to medium heat setting. This cookware should NEVER be used on a maximum heat setting for either preheating or cooking, as excessive surface temperatures can cause permanent damage to the non-stick surface. Never cut anything on the cookware or use utensiles with sharp edges, to avoid piercing the non-stick surface. Add salt to water only after it has come to a boil. Salt grain deposits on the cookware botton will attack the metal as the heat melts it down. Never use metal or plastic scouring pads to clean the non-stick surface. Never put cold water into a hot cooking utensil. Let cookware cool down on its own or place it in lukewarm soapy water. Always lift cookware. Do not slide across the cooktop. This cookware is oven safe without detachable handle up to 450 °F / 230 °C. The detachable handle is not oven safe. This cookware may become extremely hot when in use. To avoid burn hazard, always use detachable handle or pot holders or oven mitts. This cookware is dishwasher safe. Please note that certain dishwashing detergents may cause the coating to become dull and/or discoloured. Our warranty does not cover this type of wear, as the performance of the cookware is not affected. The detachable handle is not dishwasher safe. Hand wash only. The maximum total weight that the detachable handle attached to the cookware can lift is 5.5 kg / 12 lb. Please do not exceed this weight. The maximum total volume that the detachable handle attached to the cookware can lift is 5.5 L / 5.8 Qt. Please do not exceed this volume.