

QSG插页

大小: 210*148mm

材质: 128g双铜纸

颜色: 黑白双面印刷

用量: 1pc



QUICK SET UP GUIDE

ANDOVER

VWRP-3200

5-IN-1 Turntable Music Center

BASIC SETUP OF THE VWRP-3200:

1. Remove packaging materials from the unit.
2. Remove stylus/needle cover from the unit.
3. Check that the voltage on the rating plate on the back of the main unit is the same as the voltage in your area.
4. Unwrap the FM antenna and extend it fully. You may need to adjust the position of the antenna to get optimum reception.
5. Plug the small end of the power adapter into the DC jack on the back of the unit, the other big end into the wall socket.


The unit is now ready for use.

PREPARE TURNTABLE FOR PLAYING RECORDS

1. Remove cap protecting stylus.
2. Remove twist tie used to secure the Tone Arm in place.


CONNECT BLUETOOTH® IN

1. Set the Function Tuner to "BT" position. The Bluetooth Indicator starts to flash in BLUE.
2. On your external audio player, pair with the "VICTOR VWRP-3200" Bluetooth® device.
3. When the Bluetooth® connection is established, you will hear a short confirmation sound from the unit, and the Bluetooth® Indicator will turn to solid blue.



CONNECT BLUETOOTH® OUT

1. Press the Volume Tuner/Bluetooth® Out to the turn on the Bluetooth transmitter feature. The Bluetooth Indicator will start flash in ORANGE.
2. Power on your listening device (speakers, earbuds, etc.) and activate its Bluetooth® function.
3. Your turntable will automatically connect to your listening device and the flashing Bluetooth® Indicator will show breathing effect.
4. Adjust the volume on your listening device and begin to enjoy music.



* *This product has been manufactured and sold under the responsibility of NAXA ELECTRONICS INC. VICTOR and the DOG & GRAMOPHONE logo are trademarks used under license by NAXA ELECTRONICS INC. Further information at www.victor-brand.com. All other products, services, companies, trademarks, trade or product names and logos referenced herein are the property of their respective owners.*

READ THE ENTIRE USER MANUAL FOR COMPLETE UNDERSTANDING OF THE PRODUCT'S OPERATION



GUIA RAPIDA DE AJUSTES

ANDOVER
VWRP-3200

Tocadiscos Centro de Música 5-en-1

AJUSTES BASICOS:

1. Remover el material de embalaje de la unidad.
2. Remover la cubierta protectora de la cabeza fonocaptora.
3. Verificar que el voltaje del tomacorriente de su localidad corresponde con el voltaje de entrada especificado en la etiqueta de marcado del adaptador ca/cc.
4. Desenrollar la antena alámbrica de FM y extenderla completamente, ajustar la dirección para lograr una mejor sintonía de las estaciones de radio FM.
5. Insertar la salida del adaptador ca/cc al conector de entrada de Vcc de la unidad. Conectar el adaptador ca/cc a la unidad y al tomacorriente.


La unidad esta lista para operarse.

PREPARANDO LA UNIDAD PARA LA REPRODUCCIÓN DE UN DISCO

1. Remover la cubierta protectora de la cabeza fonocaptora.
2. Remover la cinta de sujeción que asegura el brazo fonocaptor en el soporte.


SINCRONIA DE ENTRADA BLUETOOTH®

1. Coloque el selector de funciones en la posición "BT", y el indicador de Bluetooth® comienza a parpadear en AZUL.
2. En el dispositivo Bluetooth® externo activar la función Bluetooth® y la búsqueda de dispositivos. Seleccionar "**VICTOR VWRP-3200**" en la lista.
3. Si la sincronía es exitosa, se escuchará un sonido de confirmación en la unidad y el indicador permanece encendido en azul.



SINCRONIA DE SALIDA BLUETOOTH®

1. Presionar el control de volumen/Salida Bluetooth® para activar la función de transmisión Bluetooth®. El indicador de Bluetooth® empezara a destellar en naranja.
2. Encender el dispositivo Bluetooth® (Bocina, Audífonos, etc.) y activar la función de Bluetooth®.
3. La unidad se conecta automáticamente con el dispositivo Bluetooth® (Bocina, Audífonos, etc.) y el indicador Bluetooth® destellante mostrara un efecto diferente.
4. Ajustar el control de volumen al nivel deseado.



• *Este producto ha sido fabricado y vendido bajo la responsabilidad de NAXA ELECTRONICS INC. El logotipo de VICTOR y de DOG & GRAMOPHONE son marcas comerciales utilizadas bajo licencia por NAXA ELECTRONICS INC. Más información en www.victor-brand.com. Todos los demás productos, servicios, empresas, marcas comerciales, nombres comerciales o de productos y logotipos a los que se hace referencia en este documento son propiedad de sus respectivos propietarios.*

LEER EL MANUAL DE OPERACION COMPLETAMENTE PARA ENTENDER LA OPERACION DEL PRODUCTO