132x192mm

FRIGIDAIRE

ET9SA3DTSC0 A 2.DOM

REFRIGERATOR FREEZER

3.8 CU FT 108 L

use & care

Warning and Safety Instructions 1
Warning and Safety Precautions 2
Diagram of Refrigerator Unit 3
Use of the Refrigerator & Freezer 3
Fruit and Vegetable Bin 4
Can Rack 4
Temperature Control 4
Interior Lamp 5
Defrosting 5
Moving and Placing the Refrigerator 6
Cleaning and Maintaining your Refrigerator 7
Vacation 8
Troubleshooting 9
Handle Install Instruction 10
Warranty 11
Product Specifications 12

USA 24h 1800 950 9953 www.curtisint.com/frigidaire

Warning and safety instructions

- Please read the Operating Instructions carefully before plugging in and using your Refrigerator.
- Please keep these instructions for future reference.
- As this product is continually updated and improved, your refrigerator may not be exactly as illustrated in this User Manual. If there is any concern please contact the authorized service agent or your seller.
- The manufacturer is entered in the manufacturer to strictly observe all warnings when operating and maintaining the refrigerator.
- The manufacturer is not responsible for any accident or damage caused by a failure to follow these instructions.

WARNING AND SAFETY PRECAUTIONS:

- The power supplied to the refrigerator must match the specifications on the unit nameplate (on the rear of the unit). Failure to do so may cause damage to the refrigerator. Curtis International Ltd. and its affiliates are not responsible for warranties not honored by the use of an improper power source.
- Installation and connection of the Refrigerator must be carried out as detailed in this User Guide.
- Parts and Accessories must be installed and used as detailed in this User Guide. If this Power Supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not tamper with or damage the refrigeration circuits.
- Electrical safety is only guaranteed when the Refrigerator is connected to a properly grounded outlet which complies with code.
- To ensure proper operation of the Refrigerator, if the unit is moved or tilted, you must wait 1 hour before plugging the unit in and turning it on.
- If the Refrigerator is switched off, or unplugged, you must wait for 5 minutes before plugging it and turning on the Refrigerator to prevent damage to the compressors.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this Refrigerator. Benzine or other flammable substances near or in the Refrigerator due to risk of fire.
- Do not operate electrical appliances inside the food storage compartments unless they are of the type recommended or approved by the manufacturer of the Refrigerator.
- Never store explosive substances in the Refrigerator.
- Glass containers, sealed, glass bottles or cans in the Freezer as they will burst upon freezing.
- Do not knock the Refrigerator in a damp or wet environment, or in a location where the Refrigerator may be splashed with water. Water penetration could weaken the electrical insulation which could result in electric shock or fire.
- Children should not be left unsupervised near the Refrigerator.
- Do not allow children to play with the Refrigerator or enter the Refrigerator in the event of suspension or when you are cleaning or replacing the unit.
- To remove the plug from the electric socket, grasp the plug firmly and pull it out. Never pull the power cord. Never touch or unplug the Refrigerator from the electric socket while your hands are wet or damp.

- Do not step on, climb on, or lean against the top of the Refrigerator, the Refrigerator or Freezer doors or the base cover of the Refrigerator.
- Do not store items on top of the Refrigerator. The items could fall and cause injury.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit. If refrigerant comes out of the Refrigerator, immediately turn off the gas supply. Do not open the Refrigerator door and do NOT operate any electrical switches. Ventilate the room where the unit is located for several hours before which could cause eye problems. Even at low doses and concentrations it irritates the eyes, nose and throat.
- Do not use the Refrigerator for the purpose of storing and freezing of food and for making ice and must not be used for any other purposes.

Diagram of Refrigerator Unit



Note: Interior accessories & layout may differ by model..

Use of the Refrigerator & Freezer

FREEZER COMPARTMENT: A compartment for storage of frozen food and making and storing a small quantity of ice.

NOTE:

When buying frozen foods, the following precautions should be observed:

1. Check that the packaging is intact.
2. Make certain the products have not exceeded their expiry date.
3. Transport frozen products home in a thermally insulated bag (where available) in shortest conveyance and in fastest. ATC 2.2.6.7
4. Once purchased, frozen foods should be exposed to as little heat as possible and should be stored in the refrigerator or freezer as soon as.
5. Before placing frozen foods in storage/open the freezer allow time to cool to room temperature.
6. Before freezing food, pack the food in a tightly sealed container or bag so that it does not dry out. Wrap meat, poultry and fish in moisture-proof paper, foil or plastic wrap. ATC 2.2.6.7
7. The following are suitable packing materials for storing frozen food: polyethylene bags, aluminum foil and freezer proof containers. All of these materials are available at most supermarkets.
8. The following are unsuitable packing materials for storing frozen food: wrapping paper, waxed paper, cellulose, cellophane, rubber bags and used shopping bags.
9. Wrap food tightly to exclude air and prevent drying out.
10. Before placing packaged food in the freezer, mark the storage date and the food item on the package with a waterproof pencil or pen.
11. Freeze all foods before they begin to deteriorate.
12. Do not overload the freezer. Place packages in the compartment doors as little as possible. Avoid loading more food in the Refrigerator or Freezer as this will cause a rise in Refrigerator or Freezer temperature.

ICE TRAY

Fill the ice tray three quarters full of water and place it in the freezer. Ice cubes can be easily released from the tray by twisting the tray with your hands.

- Bottles can burst if placed under excessive pressure.
- Do not bend the ice tray as this will break it.
- Only use containers specifically designed for making ice.

Refrigerator Compartment – designed for cooling and storing cool food but for freezing food & beverages.

Can Rack: For those Refrigerators equipped with a can rack, canned beverages can be stored using the can rack.

Freezer Compartment – designed for storing frozen food, for freezing food & beverages.

When storing food in the Refrigerator Compartment, the following instructions must be followed:

- Basic or severely cover food before placing it in the Refrigerator. This will prevent it from drying out, will help maintain its flavor and will also prevent it from affecting the odour and flavour. Sealing food covering food well will prevent the transfer of flavor and odor and will prevent food from drying out.
- Do not block the air vents which circulate cold storage.
- Make food is cool before placing it in the refrigerator.
- The top of the Refrigerator Compartment has the lowest temperature and is the area where food will stay the coldest.
- Fruit and vegetables should be placed in the fruit and vegetable storage bin.
- Keep a space between all of the foods to allow for good air flow and air circulation.
- Prevent butter, cooking oil and all baked food products from touching the plastic parts of the Refrigerator. This will prevent the plastic parts from becoming discolored.
- Beverages should be tightly sealed with cans and bottles placed upright.
- The Refrigerator Compartment door has a recessed area/cut-out to allow to prevent cold air escaping.

Fruit and Vegetable Bin: The compartment for storing fruit and vegetables.

Temperature Control. Use the temperature control to regulate the interior temperature of the Refrigerator compartment. The numbers on the knob do not represent a specific temperature, they represent a relative setting. The higher the number, the colder the temperature. For the most energy efficient, it is recommended to set the Temperature Control to the middle position.

Notes:

- The temperature of the freezer may sometimes appear to be too high. This is either because a large amount of food is stored in the refrigerator or freezer or the freezer door has been opened frequently. Normally, the internal freezer temperature will be suitably set by the unit.
- In order to keep food fresh and to save cost, the freezer temperature should be set to -18°C (0°F) or lower. The Refrigerator Compartment should be set to a warmer temperature. Frequent temperature changes should be avoided once the freezer temperature is set.
- If the refrigerator is too warm temperature is higher, the freezer temperature could be set under (Position 1), to create a less warm temperature is typically lower, the freezer temperature is set under (Position 5).

Interior Lamp: The interior lamp is rated 15 watt/E14 120V, activated by the door switch. When the Refrigerator door is opened the lamp turns on. When the Refrigerator door is closed the lamp turns off.

Defrosting.

Water condensed in front or entering the Refrigerator & Freezer by opening doors may form a layer of frost/crystals.

A automatic refrigerator efficiency and assists energy. When the frost reaches 4mm and 5mm, the refrigerator will automatically defrost.

Freezer Compartment Defrosting:

Defrosting the Freezer Compartment is performed manually. Before defrosting, remove all food from the Freezer Compartment. Switch the temperature control knob to the "0" (temperature control to "0" where the compressor will stop working) leave the freezer compartment door open until the ice and frost melt completely. Wipe up the water with a soft cloth. Switch the temperature control knob to the desired setting to be recommending before you have completed defrosting the Freezer Compartment.

WARNING: Do not scrape ice and frost with sharp tools, wooden tools, scrapers & other mechanical devices to remove ice and frost from the Freezer. This could damage the refrigerant circuit and cause damage to the Refrigerator & Freezer liner or surface of the compartments.

Refrigerator Compartment Defrosting:

The Refrigerator Compartment does not require manual defrosting. Water will be drained into the container located on the top of the compressor through a drain pipe located at the rear of the Refrigerator Compartment and will evaporate automatically. (See figure below).

NOTES:

Be sure to keep the drain hole unblocked. If blocked you may clean the blockage with a wooden stick.



Moving and Placing the Refrigerator.:

The refrigerator should be placed at a well-ventilated location. The two front feet should be adjusted to make the two adjustable rollers and to avoid vibration and noise.

Do not place the refrigerator near a heat source or expose it to direct sunlight. If the refrigerator must be placed near a heat source please ensure that there is adequate heat insulation between it and the heat source.

The refrigerator should be placed in a dry and well ventilated room. Maintain a clearance of 100mm between the back of the refrigerator and the wall. This will allow for proper air circulation and allow proper air circulation. The ventilation inlet and outlet grills and other clearance must never be covered. a clear space should be left for doors to move to 180° (See figures below).

Hill: When placing the refrigerator, discard the foam packaging materials.

When moving the refrigerator, DO NOT tilt the unit greater than 45° or upside down. (See figure below).

Cleaning and Maintaining your Refrigerator

1. Before cleaning disconnect the Refrigerator from the power receptacle.
2. Clean your refrigerator once a month.
3. Wipe the inside and outside surfaces of the refrigerator and its accessories with a damp cloth. Wipe the outside surfaces of the refrigerator with a neutral detergent to clean any stains or residue.
4. Always clean the egg keeper tray, shelves and the interior of the Fruit and Vegetable Compartment.
5. Lukewarm water with a bit of detergent is a mild disinfectant suitable for cleaning the interior of the refrigerator. Wipe the interior surfaces, including the liner and any plastic or metal trim with lukewarm, dry with soft towels. Parts can be removed for cleaning – See figure below:

6. The compressor located at the rear of the refrigerator should be cleaned a minimum of once per year. Dust of the compressor with a brush. If there is dust on the coils and fins of the condenser, clean it with a vacuum cleaner. Do not use water or detergent when cleaning.
7. Do not use detergents containing petroleum or acids must not be used. As well, the use of solvents, soap, tea towels, abrasive brushes, cleaner etc. petroleum products are HIGHLY FLAMMABLE.

Deodorizer

- Wash all the refrigerator thoroughly when using for and then no salt water.
- Remove all food and beverages.
- Clean the refrigerator.
- Leave the door open slightly to avoid possible formation of condensation, mold or odors.
- Use ordinary sodium bicarbonate with loose aerosols in the unit. The unit should not be used for 2 hours.
- Wash washers once from 4 to 6 weeks – clean the refrigerator operating normally.
- Long Vacations (More than 2 months) – If the appliance will not be used for several months, it is recommended that it be unplugged. Clean it and dry it thoroughly. To prevent odor and mold growth, leave the refrigerator and freezer doors open. Place a box of baking soda in the refrigerator compartment to remove the refrigerator and freezer compartment doors.

NOTE: Frequent unplugging of the unit will be bad for the p. Require...

TROUBLESHOOTING.

Not every problem is serious enough to warrant calling for service. Before calling for assistance, please check if the problem can be solved with the aid of the following tips.

Discard Noises:

- Check if the refrigerator is standing firmly on a level surface and if all the fixtures are secure. The refrigerator system does at the lower back of the refrigerator should not be touching each other and the compressor should not be in contact with other objects.
- Check if the back of the door panel is secure.

No Cooling:

Check that the refrigerator is plugged in. Check for a power failure, burned out/blown fuse or circuit breaker or incorrect power outlet voltage. Check the Temperature Control Knob setting.

Lamp Not Working.:

The bulb may have burned out. If so, replace the bulb with a 15W/T/Fit replacement bulb.

Deterioration of Cooling Performance.:

Check that the setting of the Temperature Control Knob is not too warm, that the refrigerator door is closed properly, that the door is not too much or that air in the freezer. Perhaps it is not being opened too frequently, that too much food hasn't been placed in the refrigerator, or that food which is too warm is being placed in the refrigerator.

Unit Stopped Working:

Check if the fuse has blown or if the power voltage is too low, the power plug is unplugged or loose, or if the temperature control is set to "0".

Food Freeze in the Refrigerator Compartment.:

Check if the temperature control is set to too low or setting and/or if stored food is in contact with the rear wall of the refrigerator compartment.

The Door has Scuff/mud after Defrosting.:

Check that the drain hole is not obstructed and that the drainage pipe has not become displaced.

Normal Phenomena:

1. Moisture Condensation may appear on the exterior of the refrigerator if stored in a humid area. Wipe off with a dry cloth.
2. You may where the door sound/click of the refrigerator is warm. This is caused by the refrigerant flowing through the pipes in the refrigerator.
3. A bubbling/gurgling noise can be heard sometimes be heard. This is caused by refrigerant flow. The refrigeration system or because the refrigerant's compressor is in start-up or shut down mode.
4. The temperature of the compressor can reach up to 80°C.

For service assistance and product information, please call: 1-866-988-9953, curtisint.com/frigidaire

THE BECKETT DRIVE, UNIT 19, MISSISSAUGA, ON, L5B 2A3 www.curtisint.com

- **Handle Install Instruction**
  - Take out the handle and the nut and screw in the package of the handle parts and 2 screws.
  - Put the handle into the hole of the door and screw in the two screws into the screw.
  - Push the handle horizontally until the handle is secure.
  - Push and pull the handle to make sure the handle is installed well.

To make a warranty claim, do not return this product to the store. Please email warranty@curtisint.com or call 1-(604)-986-9953.

2 Year Warranty

The product is warranted to be free from defects in material and workmanship for a period of 2 years from the date of original purchase. During this period, curtis will, at its sole discretion, repair or replace any defective product or component found to be defective during the warranty period. We will pay labour and material expenses for repairing the product to us. If the product or component is no longer available, we will replace with a similar one of equal or greater value. Prior to a replacement being sent, the product must be declared inoperable or returned to us.

The warranty does not cover glass, filters, wear from normal use, use not in conformity with the instructions, damage caused by accident, misuse, abuse, fire, flood, acts of nature or misuse. This warranty extends only to the original consumer purchaser or gift recipient and is not transferable. Curtis shall not be liable for any incidental or consequential warranty claim. This warranty is void if the product is used for other than single-family home use. Proof of purchase in the form of a dated cash register receipt is required to validate any of the claim (e.g., 1234-4567-xx).

We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price paid. **Some provinces do not allow the limitation of implied warranties or the exclusion of incidental or consequential damages, so the foregoing limitations may not apply to you.**

For faster service, locate the model, type, and serial numbers on your appliance.

PRODUCT SPECIFICATIONS	
Model No.	ET9SA3DTSC0 A 2.DOM
Capacity of refrigerator (cu.ft.)	3.8 CU FT
Capacity of refrigerator (L)	108 L
Power supply (V)	120 V
Rated power consumption (Watt)	60 Watts (Typ. Consumption)
Rated current consumption (Amp)	0.5 Amps
Refrigerator compartment temperature range (°C)	2°C ~ 8°C
Freezer compartment temperature range (°C)	-18°C or lower
Net refrigerator capacity (cu.ft.)	3.1 cu.ft.
Net refrigerator capacity (L)	87 L
Net freezer capacity (cu.ft.)	0.7 cu.ft.
Net freezer capacity (L)	20 L
Dimension of product (width) (mm)	475 mm
Dimension of product (depth) (mm)	475 mm
Dimension of product (height) (mm)	845 mm
Weight (net) (kg)	30 kg
Weight (gross) (kg)	32 kg

FRIGIDAIRE

welcome home

Our home is your home. Visit us if you need help with any of these things:

owner support

service

support@curtisint.com

1-(800)-668-9953

Frigidaire is a pending or registered trademark of Electrolux Home Products, Inc. and is used under license by Curtis.

FRIGIDAIRE

ET9SA3DTSC0 A 2.DOM

RÉFRIGÉRATEUR CONGÉLATEUR

3.8 PI CU FT 108 L

utilisation & entretien

Avertissements Et Instructions De Sécurité 1
Warning And Safety Precautions 2
Unité De Réfrigération 3
Utilisation Du Réfrigérateur & Congélateur 3
Deodorizer Du Bicarbonate D'ou Almonds 4
Dossier de Fruits et légumes 4
Can Rack 4
Régulateur de température 4
Lampe intérieure 5
Dégivrage 5
Déplacer et mettre le réfrigérateur 6
Nettoyage et entretien du réfrigérateur 7
Vacances 8
Dépannage 9
Livre De Garantie 10
Spécifications De Produit 11

USA Contact: ACCIONCURTIS www.curtisint.com/frigidaire

AVERTISSEMENTS ET INSTRUCTIONS DE SÉCURITÉ

- Avant d'accroître l'alimentation électrique et d'utiliser le réfrigérateur. Veuillez attentivement lire le manuel d'utilisation.
- Veuillez conserver ces spécifications pour référence future.
- En raison de la mise à jour et de l'amélioration continues du produit, votre réfrigérateur ne pourra peut- être pas exactement à l'Guide de l'utilisateur Cependant, cette ne nuira aux à la performance et au fonctionnement de votre polyvalence
- Lors de l'installation, de l'exploitation et de l'entretien du réfrigérateur, les instructions doivent être strictement suivies afin d'éviter les émissions inappropriées.
- Le fabricant n'est responsable d'aucun accident ou dommage si celui-ci du non-respect de l'une quelconque des règles suivantes.

WARNING AND SAFETY PRECAUTIONS:

- L'alimentation du réfrigérateur doit être conforme aux spécifications figurant sur la plaque d'identification à l'arrière du Installation à bride. Le réfrigérateur risque d'être endommagé si l'alimentation électrique n'est pas conforme aux spécifications. Curtis International Limited et ses filiales
- Le réfrigérateur doit être installé et connecté conformément aux spécifications du présent Guide de l'utilisateur.
- Les pièces et accessoires doivent être installés et utilisés conformément aux spécifications du présent Guide de l'utilisateur.
- Si le type électrique est endommagé, le fabricant, son agent de service ou une personne qualifiée similaire doivent le remplacer afin d'éviter tout danger pour éviter les risques.
- Ne pas altérer ou endommager les circuits de réfrigération.
- La sécurité électrique ne peut être assurée que si le réfrigérateur est relié à une prise de courant correctement mise à la terre.
- pour assurer le bon fonctionnement du réfrigérateur, si le matériel est déplacé ou incliné, il faut attendre une heure avant d'insérer la matériel et de l'allumer.
- Si le réfrigérateur est éteint ou débranché, il faut attendre 5 minutes avant d'insérer et d'allumer le réfrigérateur afin de l'éviter. afin de éviter endommager le compresseur.
- Ne pas stocker de substances explosives telles que des bombes aérosols contenant des propulseurs inflammables dans ce réfrigérateur. Benzène ou autres substances inflammables à proximité ou dans le réfrigérateur en raison du risque d'incendie. Même à de faibles doses et concentrations, il irrite les yeux, le nez et la gorge.
- Ne pas utiliser d'appareils électriques à l'intérieur des compartiments de stockage de nourriture sauf s'ils sont du type recommandé ou approuvé par le fabricant du réfrigérateur.
- Ne jamais stocker de substances explosives dans le réfrigérateur.
- Récipients en verre, bouteilles en verre scellées ou canettes dans le congélateur car elles éclateront lors de la congélation.
- Ne cognez pas le réfrigérateur dans un environnement humide ou dans un endroit où le réfrigérateur peut être éclaboussé d'eau. L'infiltration d'eau pourrait affaiblir l'isolation électrique, ce qui pourrait provoquer un choc électrique ou un incendie.
- Les enfants ne doivent pas être laissés sans surveillance à proximité du réfrigérateur.
- Ne laissez pas les enfants jouer avec le réfrigérateur ou entrer dans le réfrigérateur en cas de suspension, ou lorsque vous nettoyez ou remplacez l'appareil.
- Pour retirer la fiche de la prise de courant, saisissez fermement la fiche et retirez-la. Ne tirez jamais sur le cordon d'alimentation. Ne touchez jamais ou débranchez le réfrigérateur de la prise de courant si vos mains sont mouillées ou humides.

- Ne pas marcher, grimper ou s'appuyer sur le dessus du réfrigérateur, les portes du réfrigérateur ou congélateur ou sur le cache inférieur du réfrigérateur.
- Ne rangez pas d'objets sur le réfrigérateur. Les objets pourraient tomber et causer des blessures.
- N'utilisez pas de dispositifs mécaniques ou d'autres moyens pour accélérer le processus de dégivrage, autres que ceux recommandés par le fabricant.
- Ne pas endommager le circuit de réfrigérant. Si du réfrigérant s'échappe du réfrigérateur, coupez immédiatement l'alimentation en gaz. N'ouvrez pas la porte du réfrigérateur et ne mettez en marche aucun interrupteur électrique. Aérez la pièce dans laquelle l'appareil est situé pendant plusieurs heures avant de le brancher à nouveau. Même à faibles doses et concentrations, il irrite les yeux, le nez et la gorge.
- Ne pas utiliser le réfrigérateur à des fins autres que le stockage et la congélation des aliments et ne doit pas être utilisé à toute autre fin.

Unité De Réfrigération

Remarque: Les accessoires intérieurs et la configuration peuvent varier selon le type de véhicule.

Utilisation du réfrigérateur & Congélateur

COMPARTIMENT CONGÉLATEUR: Un compartiment de produits alimentaires congelés et congelés pour le stockage et la décharge de petites quantités de glace.

REMARQUE:

Lors de l'achat de produits alimentaires congelés, les précautions suivantes doivent être prises:

1. Vérifiez de l'intégrité de l'emballage.
2. Vérifiez si pour les produits périmés figurant pas la durée de validité.
3. Vérifiez-vous de la température de la Chambre de réfrigération pour l'achat de denrées congelées. Transportez les produits surgelés à la maison dans un sac isolant (si disponible) dans le plus court délai et dans le moyen de transport le plus rapide.
4. Une fois achetés, les aliments surgelés doivent être exposés à un minimum de chaleur et doivent être stockés dans le réfrigérateur ou congélateur dès que possible.
5. Avant de placer des aliments surgelés dans le réfrigérateur, laissez suffisamment d'temps pour qu'il refroidisse à la température ambiante.
6. Les aliments sont emballés dans un récipient ou un sac scellés pour éviter l'infiltration de l'air et l'humidité. Cela empêche également les aliments de se déshydrater. Enveloppez les aliments dans du papier aluminium, du papier imperméable ou des sacs en plastique étanches à l'air. Les matériaux d'emballage appropriés pour le stockage de denrées alimentaires surgelées sont les suivants: sacs en polyéthylène, papier d'aluminium et récipients congelables. Tous ces matériaux sont disponibles dans les grands magasins et les supermarchés.
7. Les matériaux d'emballage à éviter le contenant pas pour le stockage de denrées alimentaires surgelées sont les suivants: papier d'emballage, papier ciré, papier kraft, sac cellophane, sac en caoutchouc et sacs d'épicerie usagés.
8. Compression: l'élimination de l'air dans les emballages, lorsque cela est possible, empêche les aliments de se dessécher. Enveloppez bien les aliments pour éviter qu'ils n'entrent à des de stockage et de protéger alimentaires voisins.Avant d'mettre dans les produits alimentaires pour conserver ailleurs congelés sont congelés.
9. Lors de la congélation de denrées alimentaires, marquez le paquet avec la date de congélation.
10. Ne pas de congeler des aliments qui ont déjà commencé à se détériorer. Ils ne seront pas améliorés par la congélation. Seuls les aliments frais de bonne qualité doivent être congelés.
11. Ne pas congeler plus de nourriture que la capacité de congélation indiquée. Cela entraînerait une augmentation de la température du réfrigérateur ou de la Chambre de réfrigération.

LE BAC À GLACE

Remplissez le plein de trois quarts d'eau et mettez - la dans le frigo On peut facilement retirer facilement les cubes de glace en tordant légèrement avec vos mains.

- Les bouteilles peuvent éclater si elles sont placées sous une pression excessive.
- Ne Pliez pas le glace (parce que cela va le détruire).
- Seuls les récipients spécialement conçus pour la fabrication de glace peuvent être utilisés.

Dossier de Fruits et légumes

Compartiment de réfrigérateur - conçu pour refroidir et stocker des aliments réfrigérés mais pour congeler des aliments et des boissons.

Le compartiment réfrigérateur: Lorsque vous stockez des aliments réfrigérés dans le compartiment réfrigérateur, les instructions suivantes doivent être suivies:

La température du compartiment du réfrigérateur est calculé pour être à une certaine mesure à croissance des bactéries et ne seront donc qu 'au stockage à court terme des produits périssables.

Les aliments surgelés doivent être entreposés dans les compartiments du réfrigérateur, viande, beurre, fromage, lait, bouteilles et boissons en conserve, aliments en conserve. Fruits frais, légumes frais, pain, bonbons, crèmes, fruits et légumes.

Pour le stockage des aliments dans les chambres froides, les instructions suivantes doivent être observées:

- Emballer ou recouvrir les aliments avant de les mettre dans le réfrigérateur.Cela empêchera qu'il ne sèche et permettra le recyclage de water Huit Ils conservent longtemps, ne pas altérer leur goût et leur saveur. Cela empêchera également les odeurs de la nourriture des aliments pouvant empêcher la transfert des saveurs et des odeurs et empêcher le séchage des aliments.
- Ne pas bloquer les bouches d'aération qui maintien water froid.
- Faire refroidir la nourriture avant de la placer dans le réfrigérateur.
- Le haut du compartiment réfrigérateur a la température la plus basse et est la zone où les aliments pourront rester les plus froids.
- Fruits et légumes doivent être placés dans le bac à légumes et à fruits.
- Laissez un espace entre tous les aliments afin d'assurer un bon débit d'air et une bonne circulation d'air.
- Empêcher que le beurre, l'huile alimentaire et les aliments à base d'huile ne soient en contact avec les pièces en plastique et le revêtement intérieur du réfrigérateur. Sinon, les pièces en plastique deviendront décolorées.
- Les bouteilles doivent être hermétiquement scellées et les canettes et bouteilles doivent être placées verticalement.
- La porte du compartiment réfrigérateur dans les étoiles ne pas trotte afin de préserver sa fraîcheur d'air froid.

Courbe de fruits et légumes: Le compartiment de stockage des fruits et des légumes.

Canette: Pour le réfrigérateur équipé d 'un tiroir, les boissons en bouteilles et des cloches au casque et un tube.

Régulateur de température

Régulateur de température: Le régulateur de température est utilisé pour régler la température à l'intérieur du compartiment réfrigérateur. Les chiffres sur le bouton ne représentent pas une température spécifique, ils représentent une relation. Plus le numéro est grand, plus la température interne est basse.Il est recommandé de régler le régulateur de température au milieu.

Remarques:

- La température du congélateur est parfois trop élevée.Cela peut résulter par le fait qu'une grande quantité de nourriture est stockée dans le réfrigérateur ou le congélateur ou que la porte a été ouverte trop souvent. Normalement, la température interne du congélateur est réglée automatiquement par l'appareil.
- La température de la chambre de réfrigération doit être fixée à +5 °C (+ 1 ° à + 10 °C) = 41° parmi le réfrigérateur réduit à température ambiante normale, afin de réduire la consommation d'énergie. Des changements fréquents de température doivent être évités une fois que la température du congélateur est fixée. Il convient à Tester des variations de température fréquentes.
- Si la température du réfrigérateur est élevée en été, la température de la Chambre de réfrigération pour être fixée à une température supérieure (celle-ci est inférieure à la température la plus basse, position 1). Si la température est basse, la température de la Chambre de réfrigération peut être réglée en position 7.

Lampe intérieure: Ampoules techniques - 15w/Bc/e 14/Ses/e.g.pol 1 fonctionnent par porte.Quand la porte du réfrigérateur il 'ouvre, la lumière s'allume.Quand la porte du réfrigérateur fermée, la lumière s'éteindra.

Déplacer et mettre le réfrigérateur

Le réfrigérateur doit être placé et un niveau endroit.Ajuster les deux pieds avant pour stabiliser le réfrigérateur et empêcher les vibrations et le bruit.

Ne placez pas le réfrigérateur près d'une source de chaleur ou n'exposez pas le serait directement à la lumière du soleil. Si le réfrigérateur est placé à proximité de la source de chaleur, l'isolation thermique doit être suffisante entre la source de chaleur et le réfrigérateur.

Le réfrigérateur doit être placé dans un endroit sec et bien ventilé.Maintenir un espace de 100mm aux arrières du réfrigérateur. Cela permettra une circulation d'air appropriée. Les grilles d'entrée et de sortie d'air et les autres espaces libres ne doivent jamais être couverts. Il faut laisser un espace propre pour ouvrir ouverte à 180° (See graphique ci - dessous).

Attention: le matériau & technologie en mousse doit être abandonné lors de la mise en place du réfrigérateur.

Lorsque vous déplacez réfrigérateur, ne l'inclinez pas au - dessus de 45 degrés ou ne le retournez pas. (Voir graphique ci - dessous).

Nettoyage et entretien du réfrigérateur

1. Débranchez de la connexion du réfrigérateur Ou prise d'alimentation avant nettoyage.
2. Nettoyage du réfrigérateur une fois par mois.
3. Essuyez les surfaces intérieures et extérieures pendant le nettoyage. Essuyez les surfaces extérieures du réfrigérateur avec un détergent neutre pour nettoyer les taches ou résidus. Tissu doux. Utilisez un chiffon doux légèrement essoré de water, le savon et détergent pour éliminer les saletés.
4. Nettoyez toujours le bac à œufs, les étagères et l'intérieur du bac à légumes et à fruits.
5. Une solution d'eau tiède et de détergent est un désinfectant doux et approprié pour le nettoyage de l'intérieur du réfrigérateur. Essuyez les surfaces intérieures, y compris le revêtement et les garnitures en plastique ou en métal avec un chiffon doux légèrement essoré de water, le savon et détergent pour éliminer les saletés. Séchez avec des serviettes propres et sèches. Les pièces peuvent être retirées pour le nettoyage – Voir figure ci-dessous:

6. Le compresseur situé à l'arrière du réfrigérateur doit être nettoyé au moins une fois par an.Dépoussiérez le compresseur avec une brosse.Si il y a de la poussière sur les serpentins et les ailettes du condenseur, nettoyez-les avec un aspirateur. Ne pas utiliser d'eau ou de détergent lors du nettoyage.
7. Ne pas utiliser de détergents contenant du pétrole ou des acides ne doivent pas être utilisés. En outre, l'utilisation de solvants, de savon, de tissus abrasifs, de nettoyants pour produits pétroliers est HAUTEMENT INFLAMMABLE.

Déodorisant

- Lavez bien tout le réfrigérateur lorsque vous l'utilisez pour la première fois, puis n'utilisez pas d'eau salée.
- Retirez tous les aliments et boissons.
- Nettoyez le réfrigérateur.
- Laissez la porte légèrement ouverte pour éviter la formation de condensation, de moisissures ou d'odeurs.
- Lorsque l'unité n'a pas été utilisée pendant 2 mois ou plus, il est conseillé de débrancher l'appareil. Nettoyez-le et séchez-le soigneusement. Pour éviter les odeurs et la croissance de moisissures, laissez les portes du réfrigérateur et du congélateur ouvertes. Placez une boîte de bicarbonate de soude dans le compartiment réfrigérateur pour éliminer les odeurs du réfrigérateur et du compartiment congélateur.

Attention: le retrait fréquent/va et/une ne disponible inclut va durée de vie utile...

Dépannage

Tous les problèmes ne nécessite aucun grave que le besoin de services.Avant de demander une aide, veuillez vérifier vos problèmes pour-être résolu par les instructions suivantes.

Bruit inhabituel:

- Vérifiez-vous que le réfrigérateur ne repose pas sur une surface plane et ferme et que les éléments de fixation sont bien fixés.Le système de réfrigération situés en bonnes conditions de fonctionnement.Le compresseur situé à l'arrière du réfrigérateur ne doit pas entrer en contact avec d'autres objets.
- Le compresseur de la Chambre de réfrigération ne doit pas entrer en contact avec d'autres objets.
- Vérifiez la solidité du mure..

Sans refroidissement.:

Vérifiez si le réfrigérateur est branché On vérifie s'il y a des pannes d'alimentation, des fusibles grillés ou des disjoncteurs ou une mauvaise tension de l'alimentation. Vérifiez le réglage du régulateur de température.

Les lumières ne fonctionnent pas:

Les ampoules ont probablement grillé et il faut les remplacer. Remplacez par des ampoules de 15W/T/Fit.

Détérioration de la capacité de refroidissement.:

Vérifiez si le bouton de régulateur de température est bon réglé, si la porte du réfrigérateur est correctement fermée, s'il n'y a pas trop de glaces de givre dans le réfrigérateur, si toutes est pas trop ouverte, si trop de nourriture dans le réfrigérateur ou si les aliments chauds sont placés dans le réfrigérateur.

Arrêt du fonctionnement:

Vérifiez si la fiche est bien branchée, si l'alimentation est trop basse, si la fiche d'alimentation est retirée ou relâchée, ou si le régulateur de température est réglé à "0".

Vêtements recouverts dans la frigo.:

Vérifiez si le drainage est bouché et si le tuyau de drainage est déboîté.

Vérifiez si la température ambiante est trop basse et / ou si des aliments chauds sont en contact avec la paroi arrière du réfrigérateur.

Après dégivrage, l'eau n'est ultérieure.

Vérifiez si le trou de drainage est bouché et si les plaques de drainage situé à l 'arrière du dispositif est en position normale.

Les portes ne se ferment pas.

1. Si l'humidité intérieure est élevée, il peut y avoir de l'humidité lors condensent à l'extérieur du réfrigérateur Ce peut arriver.
2. Si vous entendez un bruit de bouillonnement, cela est normalement dû chaleur.Ceci est dû au aliment chauffant dedans à travers la condensateur et à ajouter.
3. On entend parfois des bulles / des Ceci Ceci est dû au Tuyau de réfrigérant dans le réfrigérateur. Ce bruit est dû au système compresse