95.00 mm

100.00 mm

CYGNETT **CarGo II** assembly instructions

The CarGo II is designed to attach to the headrest columns of the driver or front passenger seat. First assemble the CarGo II:

To assemble CarGo II:
Insert plastic tongue (**A**) to Slot piece (**B**). Push upwards until tab snaps into place.

To dismantle CarGo II:
Reverse assembly process.

CYGNETT Fitting **CarGo II** to headrest

1. Loosen headrest clamps (C) by turning screws (D) anti-clockwise.
2. Place CarGo II clamps (C) around headrest columns
3. Tighten the screws to hold CarGo II secure against columns of headrest.
4. Insert your tablet into cradle (E). Adjust cradle height to fit securely around tablet. Hold in place by closing latch (F)
5. Adjust the angle of CarGo II by loosening the adjustment nut (G)
6. Re-tighten nut when desired angle is reached.