







INSTRUCTION MANUAL

SUPERSONIC®

SC-1080BT



WARNING: To prevent fire or shock hazard, do not expose this appliance to rain or moisture. This equipment must be disconnected from the mains when not used.



Function Control Locations

- | | |
|--------------|-----------------|
| 1.SPEAKER | 8.FUNCTION |
| 2.BAND | 9.PREV/REW |
| 3.TUNING | 10.PLAY/PAUSE |
| 4.VOLUME | 11.NEXT/F.FWD |
| 5.DC 5V IN | 12.BATTERY DOOR |
| 6.TF CARD | 13.ROD ANTENNA |
| 7.USB DIRECT | |

ALL SORTS OF FUNCTION OPERATION METHOD:

A.RADIO

- 1.Open the volume knob VOL, Rotating the function switch to radio location, it is in a state of radio.
- 2.Turn the function switch to want to listen to the radio broadcast band, slowly turn the TUNING frequency adjustment, to see the position of the pointer like listening to radio program.
- 3.Radio, Receive FM, SW band ,pull rod antenna, and adjust direction can receive better effect,Receive AM band, Turn the machine direction, can receive better effect.

B.PLAY USB/TF

- 1.The function switch turning to MP3/BT position
- 2.Insert the USB/TF card interface, Can play normal USB/TF.
- 3.In the process of PLAY, press PLAY/PAUSE button (PLAY/PAUSE) immediately stop, press continue to PLAY again.
- 4.In the process of play, click on a Last Song (PREV) can jump on a track, click the NEXT song (NEXT) key can jump down a track, long press (designs) to retreat quickly can retreat quickly, long press fast forward (F.F WD)key can fast forward.
- 5.Rotate the VOL button can adjust the volume in your need.
- 6.When you have the USB and TF card insert this unit at the same time, the last insert USB or TF card is preferred

C.BT

1. When Switching to BT function you will hear a voice saying “waiting for the pairing”
2. Open BT on your cell phone and when the search is completed,select BT03 to pair.

3. According to the equipment prompts "yes" or "confirmation" button to confirm matching, a voice prompt "bluetooth pairing success" (bluetooth pairing success) to match at this time.
4. After the connection is successful, open the music player, can play the music in the equipment
5. In the process of play, press the radio and equipment in the button, play and pause button can be used.
6. In the process of play, according to the radio on PREV can skip to last song, according to the radio NEXT can skip to the NEXT song.
7. Because of the unit without built-in microphone that can not talk.

D. This machine can be connected computers when sound card effect, Use USB line to the machine connected to the computer USB socket, open a computer music player, can use this machine selection play computer audio files.

E. The main properties and the index

1. frequency range: AM:530-1710 KHz
FM:88-108 MHz
SW1-7:4.75-22.0 MHz

Max output power:1.5W

2. POWER SUPPLY: DC:4.5V(UM-3X3PCS)
3. USB/TF card format: MP1, MP2, MP3
4. power consumption:4W

F. NOTE:

1. When not use, Please be sure to turn off the power switch, Otherwise discharge can damage the machine built-in battery for a long time
2. When not use, Please be sure to turn off the power switch.
3. Speakers are silent, the volume is transferred to the minimum.
4. when shall give the battery charge? When playing MP3 voice was small, off and on, this unit can from external DC 5V IN rechargeable battery to directly. plug in the ac can be directly to the built-in battery charging, and can play the machine, charging time 4 to 6 hours on a full charge can play continuously for 1 hours, (better off charging).
5. An external USB device can't load more than 60 ma current. Otherwise it will damage the machine.
6. Avoid lashing and falling down the unit.
7. Avoid exposure to temperature extremes, direct sunlight and moisture.
8. Avoid to use corrosive liquid to wipe surface radio player.
9. when you are not going to use the unit for along time, remove the battery to avoid damage from battery leakage and corrosion.
10. Don't to tear open machine adjust internal components parameters