


INCLUDED CONTENTS:


- 1. Hovering Soccer Ball
- 2. Goal Frame Components
- 3. Goal Net
- 4. Phillips Screwdriver

SETTING UP THE HOVERING SOCCER BALL

- 1. Underneath the soccer ball turn the 2x cover latches to the unlock  position.
- 2. Use the included Phillips screwdriver to open the battery compartment
- 3. Insert 4x AA batteries. Taking care to match the correct polarity +/-.
- 4. Replace battery cover and turn switch on to start the hovering action.



Unscrew Battery Cover



Install 4x AA Batteries



On/Off Switch

ASSEMBLING THE GOAL

Assemble the goal by connecting the pole sections together following the diagram in alphabetical order.



★Tip. Place the a suction cup below each corner to secure the goal to a smooth floor.

f. Secure the net to the corners of the goal





For Customer Service please email:
Care@OdysseyToys.com

Please note the units model number and name in your email:
Model no. ODY-530 • Hovering Soccer Ball Set

www.OdysseyToys.com

CAUTIONS & WARNINGS

- Suitable for ages 3 and up. Adult supervision is always recommended.
- This product contains small parts which are a choking hazard. Keep away from small children.
- Manufacturers and dealers disclaim all responsibility for damage caused by misuse.
- Keep hair and loose clothing away from hovering soccer ball fans when powered on.
- If the soccer ball will be stored and unused for an extended period of time, please remove the batteries.
- Check the batteries regularly for potential leakage or corrosion that may occur.
- When installing the batteries carefully follow the polarity marking +/-.
- Do not mix different battery types.
- Remove exhausted or drained batteries.

CARE & MAINTENANCE

- Do not submerge the unit in any liquids.
- Keep the unit dry.
- Do not place the unit near powerful, un-shielded magnets.
- Do not expose the unit to extreme hot or cold temperatures.
- Do not hit, drop, or smash the unit with extreme force.
- Do not disassemble the unit for any reason.

NOT FOLLOWING THESE PRECAUTIONS WILL VOID YOUR WARRANTY.

MADE IN CHINA

