

Button Functions (Recording Stopped):



Access the dash cam's Settings menu



Takes a snapshot and stores it in the Photo Folder.



Enters the playback menu to review previous recordings and photos.



Begins loop recording.

Button Functions (While Recording):



When pressed the camera saves the current clip from being overwritten.



Takes a snapshot and stores it in the Photo Folder.





Toggles the microphone on/off. Note that the icon on the button indicates the action that will be taken when the button is pushed, not the current setting. The current setting is shown on the status bar at the top of the screen.



Stops loop recording. While in an Emergency Recording you will be asked to confirm.



SC 201 DASH CAM



QUICK START GUIDE


Scan QR Code For Additional Languages:











Red LED indicator

Camera Automatically Begins Recording

THANK YOU!

For purchasing the new COBRA® SC 201

View, edit and share from your smartphone or desktop.

Share & receive real-time driver alerts.

Download today!


drivesmarter.com/downloads





5

Download on the App Store







FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTEFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION


FCC NOTE: Modifications not expressly approved by the manufacturer could void the user's FCC granted authority to operate the

Cobra® and the snake design are registered trademarks of Cobra Electronics Corporation, USA. Cobra Electronics Corporation™ is a trademark of Cobra Electronics Corporation, USA. Other trademarks and trade names are those of their respective owners.


SC 201 Features







MicroSD Card Slot



Power Button

Mount

16GB MicroSD






Data Cable



Guide



Attach Camera Assembly to

Windshield

