

# NR-721

## OPERATION:

- Insert 2 x AAA batteries into the battery compartment, ensuring the correct polarity is observed
- Insert the earphone plug into the earphone jack if you want to listen using your earphones. Otherwise just switch in the unit using the volume control and use the speaker to listen.
- Switch the volume on/off to turn on the radio
- Adjust the volume to your desired listening level.
- Choose your radio broadcast AM or FM
- Rotate the tuning knob to your desired radio station
- Turn OFF the radio by rotating the volume control to OFF mode.

## Features:

- AM/FM Radio
- High Sensitivity Frequency
- Elegant Design
- Neck strap
- Built in Speaker

## Remarks:

- Be sure to turn off your volume control and remove your earphone from the jack when not in use.
- Always remove the batteries from the battery compartment to prevent leakage, if you are not using your unit for a long period of time.
- Do NOT mix OLD & NEW batteries.

## SPECIFICATIONS:

- Frequency Range AM – 530 – 1710 KHz & FM - 88.0 – 108.0 MHz
- Power Source – 2 x AAA Batteries (Not Included)