



One Size Fits Most

Waist Away Dimensions: ≈39.5" x 7.5"

Product Code: GF-NWT

How long can I wear my Neoprene Waist Trimmer?

The GoFit Neoprene Waist Trimmer should be worn during exercise routines to elevate the body's temperature which should assist in water and fat loss. Typically this length of time would range from 30 minutes to an hour daily.

The Neoprene Waist Trimmer and the Neoprene Shorts were not designed to be weight loss tools by themselves and should not be worn for extended periods of time as it can cause a heat rash or skin irritation if abused.

Maintenance & Care

The Waist trimmer can be hand washed with mild soap and water and then air dried.

How Often should I Check my Exercise Equipment?

GoFit equipment should always be checked thoroughly before each and every use to assure there are no nicks, tears, holes or other damage to the item. Using damaged items could lead to severe injury. If any sign of damage or wear is present, immediately discontinue use of the item and contact GoFit Customer Service for assistance.

GOFIT PRODUCT WARRANTY

This Limited Warranty applies to physical goods purchased from GoFit, LLC.

The Limited Warranty covers any defects in material or workmanship under normal and expected personal use during the warranty period.

All GoFit products are warranted for 1 year from purchase.

The Limited Warranty does not cover any problem that has arisen from:

- Use outside of a home environment or personal use.
- Damage from use of the product in a manner not directed.
- Damage from neglect or abuse
- Damage in shipping (unless shipped direct from GoFit Store)
- Any and all other situations that were not related to defect in manufacture.

To obtain warranty service, original owner of the product must contact GoFit Customer Service directly, for review of the problem and resolution appropriate to each customers' issue.