



1. Read your disc player's instruction manual thoroughly prior to cleaning.
2. Insert disc into your player label side up.
3. Select "Laser Lens Cleaning" to start the cleaning process.
4. When cleaning is complete, press stop.
5. Eject the disc and store in the enclosed holder.