# CARSON<sup>®</sup> MagniFlex<sup>™</sup>


LED Lighted Flexible-Arm Magnifier

Congratulations on selecting your new MagniFlex! In order to achieve optimum performance, please follow instructions for proper use and care.

## **PRODUCT SPECIFICATION:**


Magnification:	2x / 3.5x	Batteries:	3 AAA (not included)
Lens Diameter:	110mm (4.3")	Weight:	1.5 lbs
Flexible Neck Length:	Approx. 11"	Dimensions:	24.0" x 4.0" x 2.0"
Illumination:	LED	Accessory:	C-clamp and 4.5v DC Adapter

#### **INSTALLING BATTERIES:**



2. Insert 3 new AAA batteries in the correct polarity.


3. Replace battery door.




#### WARNING:

Use only alkaline batteries. Mixing old and new, different brands or types within brands may cause batteries to leak, overheat or explode. Keep away from fire or excessive heat. Inspect batteries for corrosion or leakage. Insert in direction indicated. Rechargeable batteries not recommended.


## ATTACHING THE C-CLAMP:



2. Place the open C-clamp onto a desk or hard surface.




3. Once put in position, tighten T-screw to hold C-clamp in place.




## ATTACHING THE MAGNIFIER:


1. When C-clamp is secured, position the magnifier bottom side down on top of the C-clamp. See image below.



#### **TURNING ON LED LIGHT:**




2. Twist the T-screw on the magnifier to tighten on C-clamp as shown below. Magnifier will be able to rotate 360°.



#### **USING THE 4.5V DC ADAPTER:**

Batteries MUST be removed when using power cord. Connect power cord to port as indicated below.





#### www.carson.com

Carson Optical 2070 5th Avenue, Ronkonkoma, NY 11779 | Tel: 631-963-5000