



### DISPLAYING CURRENT TIME, DATE AND TIMER:

Press ADV button to toggle between time, date and seconds timer.



### SETTING THE TIME AND DATE ON CLOCK:


Press SET button to toggle between setting for month, day, hour and minute.



Press ADV button to adjust month, day, hour and minute at each setting.


### USING THE MICROSCOPE:

1. Slide Light Switch (A) down to turn on.
2. Slide Microscope Light (B) down to turn On.  
**Note:** both these switches should be in the down position to operate Microscope Light.
3. Place microscope on top of object. Twist Focus Wheel until image is sharp.
4. To turn off light, slide Light




### USING THE FLASHLIGHT:

1. Slide the Light Switch (A) down to turn on.
  2. Slide the Flashlight Switch (B) up to turn On.
2. To turn off light, slide Light Switch (A) up.



### USING THE TELESCOPE:

1. Pull up to enter
2. Twist telescope



### CHANGING THE BATTERIES:

1. Unscrew the battery door.
2. Slide open the battery door as shown by arrow indicated on battery cover.
3. Replace 3 new LR-44 batteries (not included) with the correct polarity.
4. Replace battery door and screw to tighten.

### WARNING:

1. To avoid possible permanent eye damage:
  - Do not look at the sun or bright objects with the microscope.
  - Do not place the lighted microscope directly upon human eye.

### Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.



In the U S.A

Email: [info@carson.com](mailto:info@carson.com)



In the U

Email: [uksupport@carson.com](mailto:uksupport@carson.com)



In the E U

Email: [eusupport@carson.com](mailto:eusupport@carson.com)

or warranty information, visit [www.carson.com/warranty](http://www.carson.com/warranty)

[www.carson.com](http://www.carson.com)

Carson Optical 2070 5th Avenue, Ronkonkoma, NY 11779 | Tel: 631-963-5000