

STARFRIT

LADY BUG VACCUM TABLE CLEANER

Removes crumbs, ash or dirt from the table or the counter.

INSTRUCTIONS

Requires two AA batteries (not included).

Open the cover by aligning the arrows to the "open" mention on the side of the unit, then insert batteries.

To use, push the "On/Off" button towards the "On" position. This button is located on the side of the unit.

CLEANING

Open the lower housing part by pushing the "push" button at the back of the unit.

Pull the filter out and remove dirt that accumulated.

Do not immerse the unit in water.

Wipe clean the exterior with a damp cloth.