

# SOLAR LANTERN (with battery door) BATTERY REPLACEMENT INSTRUCTIONS

If your Solar Lantern stops lighting up even with 6-8 hours of direct sunlight, you may need to replace the battery as follows:

- Remove frame support wire and collapse the lantern flat to allow access to the bottom of the solar housing
- Slide the ON/OFF switch to OFF (see figure 1)
- Lift the battery door from the edge that reads LIFT (see figure 1) and remove the door to expose the battery compartment (see figure 2)
- Remove existing AAA battery and replace with the new rechargeable AAA battery.
- Replace door and snap completely closed, slide ON/OFF switch to ON, and reassemble lantern.



Figure 1




Figure 2

Please visit our website for a how-to video and for more information regarding this battery and where you may purchase a replacement:

[www.allsopgarden.com/video](http://www.allsopgarden.com/video)