PROSCAN

Smart Watch Model No.:PBTW278



This product is manufactured and sold by Curtis International Ltd.

PROSCAN is a registered trademarks of Technicolor USA used under license by

Curtis International Ltd.

Any other product, service, company, trade or product name and logo referenced herein are neither endorsed nor sponsored by Technicolor USA or its affiliates.

Safety Warning The information in this document will not be modified or extended in accordance.

with any notice.


The watch should be charged for at least 2 hours prior to initial use, please use charger and cable accredited.

"Search functions" can not be used before re-connected when watch is disconnected by far distance. Please re-connect APP by bluetooth while watch is disconnected during use. (Device must be re-connected by manual operation while disconnected for over 5 mins.)

1

2.Product details:

2.1. Product overview:



- (2). Long wristbands
- (3). Short wristbands
- (4). Display screen
- (5). Touch keys (6). USB Charging connector
- (7). Heart rate sensor

2.2.Wrist strap installation

Align the concave part of the end of the short wrist band with one end of

2

the BRACELET body with a USB plug and fix the assembly.

In the same way, attach the long wristband to the other end of the main body of the bracelet.



2.3.Wearing

Open the strap buckle and pin the strap to your wrist to adjust the tightness to the correct position. The correct position of the carpal process is preferred.



2.4.Basic functions:



Steps, calories, kilometers



Sport mode Steps,skipping,situp



Heart rate, blood pressure, blood oxygen



MAC address

This is for matching Bluetooth use.



Long press can reset watch



Camera

After connect watch with mobile phone by App, open APP "shake to phone", shake watch to control mobile phone to take pictures.



Scan it to download "profit" APP.



Phone finder

After connect watch with phone by APP, long press can look for phone.

2 5 APP Download

Scan the below QR code to download and install APP



Android 5.0 and above/IOS 9.0 and above/Bluetooth 4.0 support. First time use, scan this QR from this user manual or from bracelet 'MORE' to download this 'ProFit' app. Turn on the Bluetooth from your phone or tablet, then tap the ProFit app from your devices and tap the link icon (a), it will appear 'PF-PBTW278' here, tap to connect it. It will pop up a dialog' Bluetooth Pairing Request' from your devices, tape 'Pair' to connect it. It will sync the time and date after connected to your Bluetooth devices.

2.6.Charge

When the battery of the bracelet is low, please charge it in time. Remove the short strap to reveal the USB charging head. Insert the charging head into the standard USB charging port.

The battery icon will be flashing during charging, it will be solid after finished charging.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference to vone or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is

subject to the following two conditions:
(1) this device may not cause harmful interference, and

(2) this device may not cause frammar interference, and (2) this device must accept any interference received, including

interference that may cause undesired operation.

FCC ID: 2ATSTXG

90 days Warranty

This product is warranted to be free from defects in material and workmanship for a period of ninety (90) days from the date of original purchase. During this period, your exclusive remedy is repair or replacement of this product or component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us. If the product or component is no longer available, we will replace with a similar one of equal or greater value. Prior to a replacement being sent, the product must be rendered inoperable or returned to us.

This warranty does **not** cover glass, filters, wear from normal use, use not in conformity with the printed directions, or damage to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a warranty claim. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as on the specified rating on the label (e.g., 120V~60Hz). We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of

the purchase price. Every implied warranty, including any statutory warranty or condition of merchantability of fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited to the duration of this written warranty. This warranty gives you specific legal rights. You may have other legal rights that vay depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, inclidental, or consequential damages, so the foregoing limitations may not apply to you.

For faster service, locate the model, type, and serial numbers on your appliance.

For service assistance and product information, please call:

7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON.

1-800-968-9853 Curtis International Ltd.

L5S2A3 www.curtisint.com

To make a warranty claim, do not return this product to the store. Please email support@curtiscs.com or call 1-800-968-9853.

ATTACH YOUR PROOF OF PURCHASE HERE, PROOF OF PURCHASE IS REQUIRED TO OBTAIN WARRANTY SERVICE.

Please have the following information available when you contact the Support Team:

- Name, address and telephone number.
 Model number and serial number.
- · A clear, detailed description of the problem.
- Proof of purchase including dealer or retailer name, address and date of purchase.