

NYKO®

READ PRIOR TO USE

•• Optimal Performance Sheet ••

Nyko® Charge & Play cable directly into Nyko® battery while inside the controller



Installed

WORKS BEST

Charges and indicators are illuminated

Nyko® Charge & Play cable directly into Nyko battery outside the controller



WORKS BEST

Charges and indicators are illuminated

Microsoft® Play & Charge cable directly into Nyko battery inside controller or by itself



WORKS

Charges but indicators will not be illuminated

Nyko® Charge & Play cable into controller USB port with Microsoft® battery installed



Installed

WORKS

Charges but indicators will not be illuminated

Nyko® Charge & Play cable into controller USB port with Nyko® battery installed



Installed

WILL NOT WORK

Will not charge the battery pack

Microsoft® Play and Charge cable into controller USB port with Nyko® battery installed



Installed

WILL NOT WORK

Will not charge the battery pack

If you have any questions on the proper use of the Power Kit Plus or Power Kit for Xbox One please contact Nyko® customer support at :

Phone: +1-888-400-6956

Online: www.nyko.com

Email: customersupport@nyko.com