

The Rock 9x9" Ceramic Ovenware

Before using your new ovenware, wash thoroughly in hot soapy water using a soft cloth or sponge. Dry completely.

Never use metal scouring pads, harsh abrasives or oven cleaners to clean the ovenware.

Never cut anything in the ovenware or use utensils with sharp edges as to avoid piercing the non-stick surface.

This ovenware should not be used on the stovetop heating elements or any other direct flames.

This ovenware is oven safe up to 428F / 220C.

It will become hot when in use. To avoid burn hazard, always use pot holders or oven mitts.

The ovenware is safe for use in the refrigerator and freezer. Avoid extreme changes in temperature, as the thermal

shock may cause the ovenware to crack. Ovenware taken directly from freezer or refrigerator should never be put directly in the hot oven. Furthermore, the hot ovenware should never be put directly in the fridge or freezer. Always let the ovenware cool down to room temperature.

Always lift ovenware, do not slide across the cooktop, countertop and / or tabletop.

Do not put hot ovenware dish directly on countertop or unprotected surfaces.

Manipulate with caution. The ovenware may chip or brake if dropped onto hard surfaces.

Dishwasher safe. Take note that the shine of the coating may become dull and discolored due to the action of certain

detergents. Our warranty does not cover this type of wear, as the performance of the ovenware is not affected.