



QUICK SET UP GUIDE


COSMOPOLITAN

VWRP-4200

8-IN-1 Turntable Music Center

BASIC SETUP OF THE VWRP-4200 TURNTABLE MUSIC CENTER:

1. Determine the ideal location for the turntable. Unit should be placed on a sturdy surface away from any heat or water sources.
2. Connect the AC adaptor to a nearby power supply.
3. Unwind the FM antenna wire and extend to full length.
4. Tap the POWER/VOLUME knob to turn the unit on.




PREPARE TURNTABLE FOR PLAYING RECORDS


1. Remove cap protecting stylus.
2. Remove twist tie used to secure the Tone Arm in place.


CONNECT BLUETOOTH® IN

1. While playing audio on the VWRP-4200 device, press BT/IN button
2. Turn on the external device to receive Bluetooth® audio signals
3. Find the name of "VICTOR VWRP-4200" and connect to the device
4. After the Bluetooth® device is connected successfully, the "BT" text on the VWRP-4200 LC display screen will change from flashing to steady on.



CONNECT BLUETOOTH® OUT

1. When the host plays the audio, press BT/OUT buttons.
2. Turn on the device to receive Bluetooth® audio signals 
3. Then automatically connects to VICTOR VWRP-4200. (Note: some receiving devices need to click the link to receive the audio signal transmitted by VICTOR VWRP-4200)
4. After the Bluetooth® device is connected successfully, the emission indicator light on the host panel will change from shining to steady on.



**This product has been manufactured and sold under the responsibility of NAXA ELECTRONICS INC. VICTOR and the DOG & GRAMOPHONE logo are trademarks used under license by NAXA ELECTRONICS INC. Further information at www.victor-brand.com. All other products, services, companies, trademarks, trade or product names and logos referenced herein are the property of their respective owners.*

READ THE ENTIRE USER MANUAL FOR COMPLETE UNDERSTANDING OF THE PRODUCT'S OPERATION



GUIA RAPIDA DE AJUSTES


COSMOPOLITAN

VWRP-4200

Tocadiscos Centro de Música 8-en-1

AJUSTES BASICOS:

1. Determinar el área donde colocara el tocadiscos. Colocar sobre una superficie nivelada y estable, libre de vibración. Colocar lejos de fuentes de calor y agua.
2. Conectar el adaptador ca/cc a la unidad y a un tomacorriente. El tomacorriente debe estar cerca y ser fácilmente accesible.
3. Desenrollar y extender completamente la antena de FM.
4. Presionar “**VOLUME**” para encender la unidad.




PERPARANDO PARA REPRODUCIR DISCOS DE VINIL

1. Levantar el brazo fonocaptor del soporte.
2. Colocar el brazo fonocaptor sobre la pista inicial o la pista del disco que desea reproducir.


SINCRONIA DE ENTRADA BLUETOOTH®

1. Durante la reproducción de audio en el VWRP-4200, presionar “**BT IN**”
2. Encender el dispositivo externo Bluetooth® que emitirá la señal de audio.
3. En la lista de dispositivos encontrados seleccionar “VICTOR VWRP-4200” para sincronizarlos.
4. Si la unidad y el dispositivo externo se sincronizan satisfactoriamente, la luz indicadora en el panel del VWRP-4200 deja destellar y permanece encendida.



SINCRONIA DE SALIDA BLUETOOTH®

1. Durante la reproducción de audio en el VWRP-4200, presionar “**BT OUT**”
2. Encender el dispositivo externo Bluetooth® que recibirá la señal de audio.
3. Luego se conecta automáticamente a VICTOR VWRP-4200. (Nota: algunos dispositivos receptores deben hacer clic en el enlace para recibir la señal de audio transmitida por VICTOR VWRP-4200)
4. Después de que el dispositivo Bluetooth® se haya conectado con éxito, la luz indicadora de emisión en el panel anfitrión cambiará de brillante a fija.



**Este producto es fabricado y vendido bajo la responsabilidad de NAXA ELECTRONICS INC. Los logotipos de VICTOR y el Perro con el Fonógrafo son marcas registradas usadas bajo licencia por NAXA ELECTRONICS INC. Para más información en www.victor-brand.com. Todos los demás productos, servicios, empresas, marcas registradas, nombres comerciales o de productos y logotipos a los que se hace referencia en este documento son propiedad de sus respectivos dueños.*

LEER EL MANUAL DE OPERACION COMPLETAMENTE PARA ENTENDER LA OPERACION DEL PRODUCTO