



We want to THANK YOU for your order of the TOKK™ 3.0 Smart Wearable Assistant. We take pride in our products and want our customers to enjoy them. Please feel free to email our team and give feedback.

We want the best possible experience for you!

Email: contact@tokktech.com
Customer Service Phone Number: +1 858 999 2114 ext1.

© 2023 PRED Technologies USA Inc. All Rights Reserved.

Quick Start Guide

Step 1 Pair TOKK™ to your phone.

To Pair a Single TOKK™

Pair TOKK™ to your phone via Bluetooth®, see Bluetooth pairing on the next page. After pairing successfully your TOKK™ go to Step 2 for operation.

To Pair Two TOKK™ (to play in Stereo)

Turn both TOKKs™ on, wait for TOKK™s instructions Chime "Ready to connect" and immediatly after "Bluetooth Connected". Open your Bluetooth phone settings, select TOKK™ to connect both TOKK™ to your phone. Go to Step 2 for operation.

Step 2 How to use your TOKK™ to Play/Pause/Answer Call/Siri, etc.

Play/Pause Music: HOLD DOWN FOR TWO SECONDS to pause music, and hold down for another two seconds to replay

Access Siri, Google Now... DOUBLE CLICK TOKK's Multi-function button, wait for a short beep, voice control is now active, single click to close it.

Answer/Hang Up: SINGLE CLICK to answer, SINGLE CLICK to end.

Remote Shutter for camera: USE + / - VOLUME BUTTON to take pictures when in camera mode, great for Selfies!

For more features: check the full instruction manual in the following pages.

Bluetooth Pairing:

Please ensure the device to which you are pairing with has Bluetooth® capabilities.

1. Make sure that the TOKK™ is turned off.
2. Place the TOKK™ and your device in proximity to eachother.
3. Switch Power Button on until power is ON. A blue LED light will flash rapidly.
4. To activate the Bluetooth® mode and functions on your phone or device, see the instructions for that device.
5. Set the phone or device to search for Bluetooth® devices and select the TOKK™.
6. When the pairing is complete, the blue LED light will flash slowly. The speaker (or Speakers if you paired two TOKK™) is now ready for answering calls, listening to music or taking pictures (go to step 2 of the Quick Start Guide, or Easy Operation on the next page).

Note: Some mobile phones or other devices may pair automatically when re-started.

Main Features Specifications

- Plays in Stereo (if two TOKK's are connected)
- Magnetically attaches
- Voice dialing
- Voice control
- Voice dialing through Siri, etc.
- Active noise cancellation
- Single MIC
- Remote camera function
- Rechargeable battery
- Bluetooth 5.0
- (Rated power) PO=1.5W
- (Frequency response) 180HZ-16KHZ
- (Distortion factor) THD<1%
- (Signal-to-noise ratio) S/N≥90DB
- (Separation) ≥55dB
- (Speaker) 23mm;4Ω 1.5W
- (Playing time) 150-180mins

1. Multi function button: play, pause, answer call, Siri, etc.
2. MIC
3. Charging port



Easy Operation

Play/Pause/Answer Call/Siri, etc. (1)

- Answer/Hang Up: single click to answer, single click again to end.
- Play/Pause Music: hold down for two seconds to pause music, and hold down for another two seconds to replay.
- Siri, etc.: double click to activate assitant, single click to close it.
- Redial: triple click to redial the last outgoing number, press again to end call.

Charging Port (3)

You should fully charge the speaker prior to first use. Plug the charging cable into the micro USB port and then connect the charging cable to the USB port of your PC or other compatible power source. TOKK™ will automatically turn off when USB is plugged in to charge, and will automatically recover the previous state once the USB is unplugged.


4. LED indicator
5. Speaker



LED Indicator (4)

- When power is on, the LED light will show device is turned on.
- Blue LED light fast flashing indicates search to pair.
- Blue LED light slowly flashing indicates successfully paired.
- Red LED light steady on indicates that device is in charging mode.
- Red LED Light disappears when fully charged.
- Low battery: an alarm will sound three times to indicate the last 20mins and 5mins of battery power, along with a red & blue LED light flashing slowly

4. LED indicator
5. Speaker
6. ON/OFF
7. Volume +/- (remote camera function)



Power On/Off Button (6)

- Slide button to turn On/Off.
- Note:**
- It is strongly recommended to turn off the speaker while not in use.
- When TOKK™ and phone are disconnected over 10 minutes, TOKK™ will automatically power off to save power (despite Button in On position). You will need to switch it Off and On again to reactivate.

Volume (+/-) (Remote Camera Function) (7)

- Short slide (+) to increase the volume, slide & hold (+) to forward to the next song.
- Short slide (-) to decrease the volume, slide & hold (-) to play the previous song.
- In camera mode, short slide (+, -) to activate remote camera function.

Precautions

- Only charge the battery with the furnished USB cable (only use it in a computer USB or a DC 5V power matching the Micro USB interface to charge).
- Please keep and use in normal environments. Exposure to fire, water, or other extreme elements may damage the unit. Do not handle with wet hands.
- Keep debris or other items from blocking the device or from entering any of the ports.
- Do not attempt to open or take apart this device to avoid damage.
- Do not submerge the product in water.
- Keep device away from water and moisture - do not get it wet.
- Keep device away from any heat source.
- Adjust volume to avoid damaging your hearing.
- If the device quality deteriorates, or a slight 'popping noise' is heard, it may be due to low battery. Please recharge the device.
- Do not put any foreign objects in the USB port.
- Charge the battery in an isolated area and keep away from flammable material.
- Do not expose product to direct sunlight as it may result in a risk of battery exploding, overheating, or igniting.
- Do not disassemble, modify, short circuit or heat the battery.
- Do not place it in fire or leave in a hot place.

Trouble Shooting

No Sound

- Make sure that the music player is working and the device is charged.
- Make sure the Bluetooth is paired with the correct device.
- Make sure that your TOKK™ is in the Bluetooth range.

Not Charging

Check to make sure that you are using the correct cable and that it is fully plugged into both the device and the USB port that you are charging from. Also check to make sure the PC or other USB charger is turned on.

Disclaimer:

- It is recommended for best performance that all phone software be kept up to date.
- Bluetooth in vehicles and other devices may cause conflict with TOKK™ connectivity; please ensure you are connected to the desired device in your phone's menu.
- The quality of your TOKK™ call is entirely dependent on your phone signal strength and subsequent connection quality.
- Due to Bluetooth infrastructure outside of our control, TOKK™ might not work via Bluetooth with a computer

Caution:


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warning!

This equipment may experience difficulty and/or memory loss when subjected to any electrostatic discharge, radio frequency interference, or sudden power surge/interruption. The user is encouraged to reset the equipment should any of these occur..

PACEMAKER WARNING

TOKK™ contains a magnet. As with any magnetic or magnetically attaching device, pacemakers and other medical devices may be affected when in contact or proximity. Please consult a physician before using TOKK™ if you have any such medical devices. Wear TOKK™ on the opposite side as your pacemaker.



NOTE:

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

This Device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada License-exempt RSS-210. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Manufactured and Distributed by PRED Technologies USA Inc.
4901 Morena Boulevard, San Diego CA 92217
predtechnologies.com
Product and colors may vary.
Packaging designed in San Diego, California USA. and printed in China.
TOKK™ created in San Diego, California USA. Assembled in China.

