

PRESET TEMPERATURE ALERTS

C° / F°



RARE	63°/145°			
MED RARE	66°/151°			
MEDIUM	71°/160°	71°/160°	71°/160°	
MED WELL	76°/165°	74°/165°	74°/165°	
WELL	77°/171°	77°/171°	77°/171°	82°/180°

TEMPERATURE RANGE: 23°F TO 230°F / -5°C TO 110°C

IMPORTANT: This thermometer is meant to track food temperatures periodically throughout the cooking process, it is not oven safe and cannot be left in food during cooking.

NOTE: A plastic strip is used to prevent battery drain during shipping. Pull gently to remove before use.

CAUTION:

Thermometer may be hot after use, do not touch without protecting hands. Do not leave thermometer in the oven or grill during cooking, damage to the plastic pieces will occur.

CLEANING AND CARE:

Handwash only. Do not immerse in water or put in dishwasher.

ONE (1) YEAR LIMITED WARRANTY (EXCLUDING BATTERIES)

BATTERY PRECAUTIONS:

1. Batteries may pose a choking hazard, do not let children handle batteries.
2. Do not dispose of batteries in fire, they may explode or leak.
3. Remove batteries if product will not be used for a long period of time.
4. Always replace all batteries at the same time; do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.
5. Recycle or dispose of batteries per local regulations.

 AAA
2 BATTERIES INCLUDED



FULL INSTRUCTIONS AND WARRANTY ENCLOSED

MODEL 5262231
© 2019 Taylor, a division of Lifetime Brands, Inc.
All rights reserved. Oak Brook, IL, 60523

Made in China

For warranty information please call 1.866.843.3905
or visit us online at: TAYLORUSA.COM



Place
Sticker
Here



1473_7.29.19