

Mounting location:

Place the rain gauge in an open area away from a roof line or water runoff. For accurate measurements, do not place near water runoff from a roof line or any other structure.

Mounting instructions:

1. Use included screws to mount on a post or fence, or
2. Slide the bottom of the rain gauge into the reversible mounting bracket and place the stake end of mounting bracket into soft ground away from water runoff.