




# QUICK SET UP GUIDE

## METRO VSRP-800

### Dual Bluetooth® Suitcase Turntable

#### BASIC SETUP OF THE VSRP-800 SUITCASE TURNTABLE:

1. Connect the power adaptor to a nearby AC outlet.
2. Turn on the unit by turning the POWER/VOL knob and the power LED indicator lights up. Your system is now ready to play your music. Please refer to the Operations section of this manual for details.



#### PREPARE TURNTABLE FOR PLAYING RECORDS

1. Remove cap protecting stylus.
2. Remove twist tie used to secure the Tone Arm in place.

#### CONNECT BLUETOOTH® IN

1. Switch the knob to Bluetooth® mode. A blue LED will begin flashing and a voice indicates the turntable is in pairing mode.
2. Search for the turntable in the list of Bluetooth® devices named "VICTOR VSRP-800" and connect.
3. A chime and a steady blue LED light will indicate you have paired with the turntable successfully.



#### CONNECT BLUETOOTH® OUT

1. Turn on pairing mode on your Bluetooth® speaker.
2. Turn the Bluetooth® knob to the "BT Out" position on the turntable. The LED light flashes to indicate the device is searching for an available Bluetooth® speaker.
3. When the turntable connects to the Bluetooth® speaker, the LED light stays lit. After the speaker is paired successfully, turntable audio signal can be transmitted.



*\*This product has been manufactured and sold under the responsibility of NAXA ELECTRONICS INC. VICTOR and the DOG & GRAMOPHONE logo are trademarks used under license by NAXA ELECTRONICS INC. Further information at [www.victor-brand.com](http://www.victor-brand.com). All other products, services, companies, trademarks, trade or product names and logos referenced herein are the property of their respective owners.*

**READ THE ENTIRE USER MANUAL FOR COMPLETE UNDERSTANDING OF THE PRODUCT'S OPERATION**