

BugLoupe™

4.5x Power Pre-Focused Stand Magnifier Loupe

Congratulations on selecting your new BugLoupe Stand Magnifier Loupe! In order to achieve optimum performance, please follow instructions for proper use and care.



PRODUCT SPECIFICATION

Magnification	4.5x
Weight	0.42 lbs
Dimensions	4.2" x 4.2" x 3.0"

USING LOUPE

1. Place loupe over viewing subject.
2. Your eye(s) should be reasonably close to loupe.
3. It's best to start with loupe flat against a table and raise as needed to focus.

CARE

Clean using microfiber lens cloth. Do not use any abrasives, chemical cleaners, or solvents.

WARNING

Fire Hazard - Keep loupe away from direct sunlight to prevent accidental fire.

Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.



✉ info@carson.com



✉ uksupport@carson.com



✉ eusupport@carson.com

For warranty information, visit www.carson.com/warranty

www.carson.com

Carson Optical 2070 5th Avenue, Ronkonkoma, NY 11779 | Tel: 631-963-5000