

EcoCopper - 11" (28cm) Fry Pan

CARE & USE INSTRUCTIONS

Before using your new cookware, wash thoroughly in hot soapy water using a soft cloth or sponge. Dry completely.

Prior to each use, it is recommended to add a teaspoon of cooking oil for better cooking results.

Never heat an empty utensil. Be sure there is oil, butter, liquid or food before placing the cookware on the range or burner.

It is not recommended to use high heat. Cooking on excessive heat can cause permanent damage to the non-stick coating.

Never cut anything in the cookware or use utensils with sharp edges as to avoid piercing the non-stick surface.

Never use metal scouring pads to clean the non-stick surface.

Never put cold water into a hot utensil. Let cookware cool down on its own or place in lukewarm soapy water.

If using a ceramic stovetop, lift the pan rather than sliding it across the glass plate.

This cookware is oven safe up to 428 °F / 220 °C. Always use gloves or oven mitts when using as the handles may become hot.