

29" HD Soundbar with Bluetooth Wireless

User's Guide for Model ITB037BO v2268-01



FCC WARNINGS

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ADDITIONAL WARNINGS

- **WARNING:** Shock hazard - Do Not Open.
 - Caution and marking information is located at the rear or bottom of the apparatus.
 - Mains plug is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.
 - **CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.**
 - Objects filled with liquids, such as vases, shall not be placed on the apparatus
 - **WARNING:** Do not place this unit directly onto furniture surfaces with any type of soft, porous, or sensitive finish. As with any rubber compound made with oils, the feet could cause marks or staining where the feet reside. We recommend using a protective barrier such as a cloth or a piece of glass between the unit and the surface to reduce the risk of damage and/or staining.
 - Only use the included power supply or a UL/ETL certified power supply of the same power output specifications.
- ⚠ WARNING :** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. **This product meets and complies with all Federal regulations.**


Overview

Features


- Voice prompts announce speaker functions
- Bluetooth Wireless: 60 ft. range
- Built-in stereo speakers
- Line In (3.5mm audio input)
- Optical digital audio input
- RCA stereo audio inputs
- Wall mountable
- DC power input

Includes



- RCA stereo audio cable
- Wall Mounting hardware & instructions
- AC/DC Power adapter
- Remote control & battery



Front



Rear



Optical Audio Input

Aux In
Requires RCA stereo audio cable (included).

DC Power Port

Wall Mounts

Right Side Controls & Input

Power/Source

Press to power ON.
Press and hold to power OFF.
Press to change audio source.

Volume +/-


Press to adjust the volume up or down.

Pair

Press to begin pairing to a Bluetooth device.

Line In

Requires 3.5mm audio cable (not included).



Remote Control & Battery

Power

Press to power ON/OFF.

Mute

Press to mute audio.

Bluetooth

Press to switch to Bluetooth audio source. *Remote does not initiate pairing, use Pair button on speaker.*

Aux/Line In

Press to select Aux In/ Line In source.

Optical

Press to select Optical audio source.



Skip Back/Fwd

Press to skip the selected track (BLUETOOTH MODE).

Play/Pause

Press to play or pause the selected track (BLUETOOTH MODE).


Volume +/-



Remote requires 1 CR2025 button cell battery (included).

Power

Plug the AC/DC power adapter (included) into the DC Input on the back of the unit and a standard wall outlet.



Bluetooth Wireless Audio

Pairing to a Device & Playing Audio

After initial pairing, the unit will stay paired unless unpaired manually by the user or erased due to a reset of the device. If your device should become unpaired or you find it is unable to connect, repeat the steps listed here.

1. Power ON the soundbar and press **Source on the soundbar** or **Bluetooth on the remote** to select **Bluetooth Mode**. Press the **Pair button** to begin pairing. The **Pairing Indicator** will begin quickly flashing blue. When pairing, remain within 3 feet of the unit.
2. Using the controls on your Bluetooth device, search for and select **ITB037** in your Bluetooth settings to pair. If your device requests a password, enter the default password **0000**. If need be, refer to the user's manual for your specific device for instructions on connecting Bluetooth devices.
3. When successfully paired, the **Pairing Indicator** will turn solid, an audible chime will sound and a voice will announce the connection. Use the controls on the connected device to select and begin playing audio.


Previously Connected Devices

- The soundbar can remember multiple Bluetooth devices and will always try to re-connect to the last device used.
- To re-connect to a different device, turn off Bluetooth on unwanted devices, then access the Bluetooth settings menu on the device you wish to use and select **ITB037**.

Aux In (Stereo RCA Inputs)

Requires RCA stereo audio cable (included). When connecting an RCA stereo audio cable (Red/White), match the colored ports to their corresponding plugs.


1. Connect the RCA stereo audio cable to the Aux Inputs on the soundbar and the audio outputs on a television or other audio source.
2. Power ON the soundbar and press **Source on the soundbar** or **Aux/Line In on the remote** to select **Aux In Mode**. A voice will announce the source mode and the indicator will turn green.
3. Audio played through the television or other source should now be heard through the speakers.



Optical Input

Requires: An audio source with an Optical Audio Output and a Digital Optical Audio Cable (not included).

1. Using a **Digital Optical Audio Cable**, connect the optical output on your audio source (TV, amplifier, etc.) to the **Optical Input** on the soundbar.
2. Power ON the soundbar and press **Optical on the remote** or **Source on the soundbar** to select **Optical/SPDIF Mode**. A voice will announce the source mode and the indicator will turn orange.
3. On the connected audio source (TV, amplifier, etc.), make sure the audio settings are set to **PCM or Optical Audio** and are turned on.
4. Audio played through the connected audio source (TV, amplifier, etc.) should now be heard through the speakers.




Important tips for optical audio:

- Use the correct toslink cable and make sure that it is firmly seated in both source and sound bar sockets.
- Optical output is activated on the source (they should see a red light emitting from the toslink socket). It may be labeled SPDIF in the setting menu of the source.
- The optical output is set to output PCM and not Dolby Digital.

Line In

Requires a 3.5 mm audio cable (not included).

1. Using a 3.5 mm audio cable, connect the **Line In** on the soundbar to the audio output/headphone jack on a smartphone or other audio source.
2. Power ON the soundbar and press **Source on the soundbar** or **Aux/Line In on the remote** to select **Aux In Mode**. A voice will announce the source mode and the indicator will turn green. Connecting via Line In overrides the Aux In source. Remove the 3.5mm audio cable to hear the Aux In source again.
3. Audio played through the connected device should now be heard through the speakers. Use the controls on the connected device to play, pause, or skip selected tracks.



International Support

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at: www.iLiveElectronics.com

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en: www.iLiveElectronics.com

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur: www.iLiveElectronics.com

For Warranty Information and the most up-to-date version of this User's Guide, go to www.iLiveElectronics.com

Customer Service: 1-888-999-4215 | **Email Support:** prodinfo@dpiinc.com | **Email Parts:** partsinfo@dpiinc.com

Copyright © 2017 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.



**Protect for Today
Sustain for Tomorrow**