



## PPRH7DS / PPRH7DS Quick Start Guide

### V33459 Stanley® FatMax® 1400 Peak AMP Power Station with Digital Display

#### 700 Amp Jump Starter

*Always consult your product Instruction Manual before operation*

1. Turn off ignition and all accessories (lights, radio, A/C, etc.) and be sure the vehicle is in park.
2. Make sure the Jump-starter power switch is turned off.
3. Connect the jump-starter's positive and negative clamps according to the connection method specified in your vehicle's instruction manual.
4. Please note if the red LED is lit and the audible alarm sounds the unit is connected in reverse polarity and you must adjust your connection.
5. When the clamps are properly connected, turn on the jump-starter's power switch.
6. Turn on the ignition and crank the engine in 5-6 second bursts until the engine starts.
7. Turn off the jump-starter power switch.
8. Disconnect the jump-starter's positive and negative clamps according to the connection method specified in your vehicle's instruction manual.
9. Recharge your unit after each use and every 60 days to maintain the internal batteries life.



#### 500 Watt Inverter

*Always consult your product Instruction Manual before operation*

1. Plug in an AC device into one of the 120V AC outlets on the front of the unit.
2. Turn on the inverter power switch on the unit's control panel.
3. Do not exceed 500 watts.
4. Check the battery status LEDs to monitor the units charge level.
5. Recharge the unit when only one red LED illuminates when pressing the battery status button.

#### Recharging:

*Always consult your product Instruction Manual before operation*

1. Lift the AC cover on the front of the unit near the handle and connect an extension cord to the built in AC adapter.
2. Plug the other end of the extension cord into a live 120V AC wall outlet.
3. Recharge until all of the battery status LED's illuminate.
4. Once fully charged, disconnect the extension cord.