






## Package Contents




Sensor Hub



Power Accessories



Bracket



Pin


## LED Behavior

See the table below for definitions of the hub's LED behavior:


Behavior	Meaning
● (solid)	Disarmed mode activated.
● (flashing)	Ready for network connection.
● (flashing rapidly)	Ready to pair. Press button.
● (solid)	Home & Away mode is activated /or rebooting.
● (flashing)	Trying to connect to network.
● (flashing rapidly)	Alarm has been triggered.
● ● (alternating)	Firmware upgrade in progress.

## Overview

Front view



Back view



## STEP 1: Connecting to the Lorex Home App

### To pair your sensor hub to the Lorex Home app:

1. If you already have the app, skip this step. Scan the QR code and install the free **Lorex Home** app from the App Store or Google Play Store.



2. Tap the Lorex Home icon to launch the app.



3. If you already have an account, skip this step. Tap **Sign up**, then follow the on screen prompts to create an account.

Record your account details below:

Email: \_\_\_\_\_

Account Password: \_\_\_\_\_

4. Connect the power cable to the included USB adapter and plug into a nearby outlet. Plug the other end of the power cable into the power port of your hub.
5. Once the status LED on your hub is flashing blue and the startup chime sounds, tap **+**.

6. Scan the QR code on the bottom of your hub using your mobile device's camera.

**NOTE:** If your mobile device cannot scan the QR code, tap **Manually enter Device ID**.

7. Create a secure password for your hub. Record your hub's password below:

Hub Password: \_\_\_\_\_

The Lorex Home app will walk you through the rest of the setup process, step by step.

## STEP 2: Installing the Hub

### Location tips:

- The hub can be installed indoors on any flat surface.
- The hub must always be connected to the power adapter.
- The optimal position for the hub is central to where the sensors are installed and within range of the WiFi router.

### To install your sensor hub to a surface area:




1. Pick a central area for the hub sensor to be placed.

**NOTE:** Install close to an outlet for the power adapter. Make sure the power cable is not strained.

2. Pair the sensors to ensure that the connection to the hub is steady based on their designated locations.


3. Twist the supplied bracket clockwise to the back of the hub. Be sure to follow the "UP" direction.

4. Peel the bracket's adhesive and stick the hub to the desired surface area.



## Home, Away, and Disarmed Mode

The sensor hub's settings will list all of the linked devices. Here, you can tap **+** to add a sensor or adjust the security mode.



Tap the icon to choose between one of the three security modes:



**Home Mode:** Only perimeter sensors will be monitored.




**Away Mode:** All sensors will be monitored and an alert will be sent if they're triggered.



**Disarmed Mode:** No sensors in your home will be monitored and no alerts will be sent.

You have the option to specify which sensors will be armed or disarmed in the set mode.



For complete instructions on using the app, see the Lorex Home app manual on the product page at [lorex.com](http://lorex.com).