

---

# User Manual of BLE Gateway Plug

## 1. Function Summary

SK517-WBG is a single outlet smart BLE gateway plug, which can be controlled by Tuya "Smart life" APP, equipped with remote control, timing and other functions.



Product Picture

---

## 2. Product Parameter

Appearance	
Model#	G3
Dimension	50*50*50mm
Color	White
Weight	53g
Parameter	
Input Voltage	125VAC/60Hz
Load Power	15A Max. 1875W resistive ; 5A Max. 625W tungsten
Standby Power Consumption	OFF status : 0.2~0.4 W(static state); 0.5~0.8W(Communication/Pairing Network State)
Operation Temperature	0°C to 40°C
Mobile phone system requirements	iOS 8.0 and above ; Android 4.4 and above

---

## 3. Using Instructions

### (1) Product description

The G3 is a US standard single outlet smart BLE gateway plug. It can control the ON/OFF and set the timing remotely via APP. Before using the function of the device, it is necessary to pairing the network firstly, so that the product can connect to the Internet through WIFI, which can be a router or a mobile hotspot.

There is a button and an indicator light on the housing of the product. There are two types of button operations: click and long press.

- Click: turn on/off the socket, the blue indicator will light up when it is on and off when it is off.
- Long press: to enter the EZ pairing mode, and the blue indicator will flash quickly, then you can follow the EZ pairing mode steps for pairing device; When it flashes quickly, long press again to enter the AP pairing mode, and the blue indicator will flash slowly, you can follow the AP pairing mode steps for pairing device

The Bluetooth gateway function can be configured in the APP, that is, other Bluetooth devices can be added to the gateway.

### (2) APP using steps

- Download the App

Scan the below QR code or search for "Smart Life" in the app shop to download and install the app.



---

- **Using of APP**

- Enter the APP , register and login

- **Pairing**

1) EZ pairing mode: When the product is not paired with the network, the device will automatically enter EZ pairing mode when it is powered on, and the indicator will flash quickly. At this time, open the APP for pairing. Or long press the button for 5S to enter EZ pairing mode.

2) AP pairing mode: When the indicator flashes quickly, long press the button for 10S, the indicator will flash slowly, at that time, the device will enter into the AP pairing mode. Open the APP and follow the steps to pairing.

3) The gateway adds a new device

---

#### FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### Note:

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body